


General recommendations:

- During the installation observe the compulsory security standards - wear protective gloves and work clothes with long sleeves.
- During transport and storage, protect against mechanical damage.

STEP 1

Delivery of Topform 2000 as final elements - cut to size.




STEP 2

Adding of Topform 2000 elements.



STEP 3

Connecting of elements by steel sheets using screws.



STEP 4

Concreting of elements.

