

General recommendations:

- During the installation observe the compulsory security standards - wear protective gloves and work clothes with long sleeves.
- During transport and storage, protect against damage.

STEP 1

Setting of precast beams on girders.



STEP 2

Setting of Rebox.



STEP 3

Closing the Rebox by cover.



STEP 4

Reinforcement installation. Concreting.

